

# SONIC AIR 23L

HUMIDIFIER



INSTRUCTION MANUAL

# WARNING

## **ENSURE YOU READ THE INFORMATION MANUAL ENTIRELY PRIOR TO FIRST USE TO AVOID THE RISK OF ELECTRICAL SHOCK/FIRE/INJURY.**

Do not immerse the humidifier base unit, plug or power cord in water or any other liquid. Protect the humidifier mains connection from all liquid. The humidifier is designed for indoor use only.

Check the power cord and plug every time you use the humidifier, if any are damaged, DO NOT USE. Contact the manufacturer for advice on repair.

If any damage is detected, immediately discontinue use and isolate the unit from the mains electrical supply.

Protect the power cord from heat, DO NOT position the humidifier or the power cord directly onto a hot surface.

Always ensure the product is switched off at the mains before unplugging.

Ensure the power supply used is 230VAC  $\pm$  10% and the frequency is 50Hz. Use of incorrect voltage or frequency will void the warranty.

The mains plug is not replaceable, and changes to the plug will void the warranty. The plug has a replaceable fuse, in the event of failure, remove the plug from the electrical supply. Using a small screwdriver prise the fuse carrier from the plug, replace the 3 Amp fuse in the carrier and push back into the plug.

The use of an RCD (Residential Current Device) and surge protector is highly recommended with this product.


The humidifier can be cleaned by disconnecting it from the mains electricity and wiping it with a soft cloth.

DO NOT open or modify this appliance (this will void the warranty).

DO NOT use an extension cord with this product.

# THANK YOU FOR PURCHASING THE SONIC AIR 23L HUMIDIFIER.

Please take a moment to read the instruction manual before using the appliance.



Voltage/ Frequency	Power	Capacity	Maximal Output	Noise Level
230VAC $\pm$ 10%/50-60Hz	110W	10L	1440ml/h	$\leq$ 35dB(A)

## PRECAUTIONS

1. In case of any abnormal sounds or smells during operation, immediately disconnect from the mains power supply. Return the humidifier to the supplier.
2. Do not turn on the humidifier if there is no water in the unit.
3. Do not move the humidifier while in operation.
4. Turn the unit off and remove from the power source before cleaning, adding water or moving the humidifier.
5. Do not put any metal, chemical or abrasive compounds into the base unit. This will negatively affect the humidity function.
6. Do not scrape the ultra sonic disks with hard objects. Clean only with a soft cloth. Do not use chemicals.
7. Take care when cleaning or moving to prevent water spilling into the inside of the base unit as this is likely to damage the internal components.
8. Do not let water enter the air outlet in the base unit. If there is water on the base unit, clean it with a dry cloth.
9. Switch off and disconnect the unit before emptying the water from the base.
10. Repairs must be conducted by a professional qualified electrician.
11. Pay attention to the environment to ensure normal operation of the humidifier and avoid unnecessary accidents.
12. Do not use water over 40°C. This could cause serious damage to the product.
13. Don't use the humidifier in rooms with temperatures over 45°C.
14. Remove all water from the water tank and the base unit before storage; especially if storing where temperatures could drop below 0°C.
15. Always keep the unit out of the reach of children.

## MAINTENANCE AND CLEANING

Clean the water tank every two weeks: Remove the filling cap, clean the inside of water tank with a soft cloth and rinse out using purified water.

Clean the base unit once a week: with a soft cloth or a soft brush, rinse out using purified water.

Clean, mop up or dry all parts of the humidifier by airing, before storage. Store the unit in the original packing box.

## HOW TO OPERATE

The unit can be filled manually through the water tank filler lid, it can also be connected to an external water tank. An optional float valve kit is needed to connect the unit to a water tank. SAH-23KIT

1. Place the unit in a suitable location on a flat, level surface.
2. Unplug the unit from the mains.
3. Lift the water filler lid on the top of the water tank and fill with water up to the MAX. mark inside the tank, please note hard water will damage the ultra sonic disks and will void the warranty. Purified or RO water should be used.
4. Reconnect the mains power and adjust the control knob and the unit will start to produce water vapour.
5. Turn the control knob clockwise to increase the volume of water vapour, and anti clockwise to reduce it.
6. The power LED is green when the unit is operating, it will turn red if the unit runs out of water.

**Please note:** you must switch off the electrical supply when refilling, this resets the unit so it will operate when the tank is refilled. Only turn the unit back on once the tank is refilled.



Water filling lid



**Please note:** the control knob turns the unit on and off and also regulates the volume of mist.

Power indicator	Normal operation	Low or no water
Single light	Green	Red

## TROUBLESHOOTING

If the machine doesn't work properly, please check the following before contacting the supplier.

<b>Problem</b>	<b>Possible cause</b>	<b>Solution</b>
Power light off, no airflow and no mist	Power is disconnected	Connect the power supply and turn it on
	Main switch is off	Turn the control knob on
Power light on, no air flow and no mist	Water level is too high in the base unit	Clean & dry the base unit
Little output of mist	Encrustation formation on the ultra sonic disks	Clean the ultra sonic disks
	Dirty water or water stored for too long	Replace with clean water
The water in the tank does not flow down	The hole in the water tank cover is blocked	Clean the blocked hole
	The water level is above the max mark in the tank	Pour out some of the water in the tank

If the humidifier still doesn't work, please return the product to the supplier for more assistance.

For electrical products sold within the UK and the European Community. This symbol means that this product must not be placed into general waste at the end of the electrical product's useful life. It should be sent to a separate recycling facility. Check with your Local Authority for recycling advice in your country.

By recycling responsibly, it will help protect the environment and human health.



### **CE Declaration of Conformity**

This products conforms to the essential requirements of the following EU safety directives:

- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU

### **UKCA Declaration of Conformity**

This product conforms to the essential requirements of the following UK directives:

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016



**01226 748613**

**INFO@GLOBALAIRSUPPLIES.CO.UK**

**WWW.GLOBALAIRSUPPLIES.CO.UK**